

**Flag Staff Mount Installation – Chrysler/ Dodge Mini Van
Part #: 40193**

1. Mounts are left side and right side specific. The left (driver side) flagstaff mount is marked with 'L' and the right (passenger side) with 'R'.
2. Place the flagstaff base into the flagstaff mount and secure with the 3/8" nut and lock washer (supplied) before installing the mount.
3. Open the hood.
4. With the proper flagstaff mount go to the right (passenger side) or left (driver side) of the vehicle.
5. Along the length of the lip, where the hood sits when in the closed position, there are 4 hex head screws spaced about 7" apart.
6. The second screw in, from the front of the van, is the location of the mount.
7. Back the screw out 1/4" - 1/2" using a 10mm wrench.
8. Slide the slot, of the mount, over the backed out screw.
9. Insure the top of the mount is out over the fender and it is positioned so that the flagstaff will be vertical.
10. Tighten down the screw to hold the mount in place. (Do not over tighten!)
11. SLOWLY lower the hood to insure clearance between the edge of the hood and the mount.
12. Repeat the process on the other side.