

Flag Staff Mount Installation – Cadillac (1997-1999)
Part #: 40145

1. Cadillac flagstaff mounts are left side and right side specific. The left (driver side) flagstaff mount is marked with 'L'.
2. Open the hood.
3. Note the lips on the fenders, above the front wheels.
4. Select the desired location along the fender for the mount.
5. Hold the mount against the fender with the 3/8" hole over the fender. The mount should be at 90 degrees to the ground. A small level on top of the mount will help to determine 90 degrees to the ground. Mark one of the smaller hole locations on the inner fender.
6. At the hole location marked on the inner fender drill a 7/64" hole.
7. Secure the mount to the fender using a 5/8 inch #6 stainless steel pan head metal screw. A little grease in the drilled hole will help prevent the fender from rusting.
8. Try carefully closing the hood after each installation to ensure the hood clears the flagstaff mount.
9. Adjust the mount to 90 degrees and drill the second 7/64" hole.
10. Finish securing the mount with a second screw.
11. Once you are satisfied with the mount installation, attach the flagstaff base to the mount using the stainless steel nut and washer supplied.